

## **1.0 GENERAL**

### **1.1 INTENT**

- .1 This section specifies requirements for the excavation and remediation of hydrocarbon contaminated soil if discovered on the Site. The Contractor shall excavate, load, haul and dispose of any contaminated soils or material to an approved Off-Site disposal facility.

### **1.2 DEFINITIONS**

- .1 “Landfarming”: is an ex-situ bioremediation technology in which the contaminated soil is excavated and positioned in specified layers in a treatment area that will control leaching of contaminants. The soil is periodically turned over or tilled to aerate the contaminant and optimize the rate of contaminant degradation.
- .2 “ALLU Bucket”: an attachment that is installed in place of the bucket on a loader or excavator. ALLU Bucket’s bucket has rotating drums that are controlled by the operator which break up and aerate the excavated contaminated material in a separate pile after ALLU Bucket treatment.

### **1.3 TESTING OF MATERIALS**

- .1 At the discretion of the Owner, any fill materials may be tested before placement to confirm suitability for intended uses.
- .2 Submit fill material samples to the Owner for Standard Proctor Density Testing at least 7 days prior to placement.

## **2.0 PRODUCTS**

### **2.1 FILL MATERIALS**

- .1 Refer to Section 02330 Earthwork Materials for fill material specifications.

## **3.0 EXECUTION**

### **3.1 SITE PREPARATION**

- .1 Notify Alberta One Call and locate all member-company utilities including sewer, power, gas, telephone and others. Utilize a private utility locator to verify the Alberta One Call locates and identify the locations of any private utilities or services. Locate all utilities before proceeding with the excavation.
- .2 Coordinate with utility company to remove or relocate utility lines as required to safely undertake the Work of this Contract.

- .3 Expose existing utility lines in the work area by hand excavation or hydrovac to confirm location before machine digging within 600 mm of lines.
- .4 Remove surface obstructions in the work area.
- .5 Prior to commencement of site excavation activities, install temporary chain-link fence, 1.8m high, to secure the excavation area. The chain link fence should provide access for vehicles and equipment but must be locked when no work is occurring onsite.
- .6 Attach signs to temporary fencing on four sides of the excavation prior to the commencement of the soil excavation. Signs must indicate that site access is restricted to;
  - .1 authorized personnel only,
  - .2 identify safety requirement (i.e., hard hat, safety boots, etc.),
  - .3 provide a telephone number for inquiries and emergency contact.
- .7 Confirm stockpile area for clean overburden and topsoil with Owner's representative.

### 3.2 EXCAVATE AND STOCKPILE UNCONTAMINATED TOPSOIL AND OVERBURDEN

- .1 Saw, cut and remove asphalt or concrete required for excavation and dispose at approved location or landfill.
- .2 Direct runoff away from, or around, excavation.
- .3 Strip topsoil, uncontaminated overburden including granular materials and stockpile separately on site in area indicated on drawings. Do not mix materials.
- .4 Remediate soil to comply with the criteria established in the Risk Management Guidelines for Petroleum Storage Tank Sites dated October 2001 (or latest edition). Remediation criteria for this site is based on:
  - .1 Soil Type: Fine grained
  - .2 Land Usage: Residential
- .5 Remediate soil to meet or exceed the following minimum remediation criteria:

#### **Remediation Criteria for Generic Hydrocarbon and Lead**

---

<b>Parameter</b>	<b>Concentration (mg/kg)</b>
Benzene	0.046
Toluene	0.52
Ethylbenzene	0.073
Xylenes	0.99
F1 (C6-C10)	210
F2 (C10 – C16)	150
F3 (C16 – C34)	1,300
F4 (C34 – C50)	5,600
Lead	140

### **3.3 ALLU BUCKET TREATMENT OF HYDROCARBON CONTAMINATED MATERIAL – NOT USED**

- .1 Prepare ALLU Bucket Treatment Area
  - .1 Construct ALLU Bucket treatment area in location shown on drawings.
  - .2 Construct ALLU Bucket treatment area to accommodate all material to be treated.
- .2 Excavate Hydrocarbon Impacted Soil and Treat to Remediation Criteria
  - .1 Excavate to elevation and dimensions as indicated by Owner.
  - .2 Transport hydrocarbon impacted soil to ALLU Bucket treatment area. Stockpile within bermed area.
  - .3 Treat material to criteria using the ALLU Bucket process until it meets specified criteria. Replace and compact treated material in excavation.
  - .4 Pass hydrocarbon impacted soil through ALLU Bucket treatment and stockpile within bermed area to contain runoff, pending direction from the Owner. The Owner will sample and analyze treated soils to confirm hydrocarbon concentrations using an independent laboratory on a regular turnaround basis to determine if additional ALLU Bucket treatment passes are required. No payments will be made for standby time while waiting for the results of the confirmation samples. Ensure that treated material meets applicable criteria.
  - .5 Assist Owner in collection of representative soil and water samples for the base and walls of the excavation.
  - .6 Direct surface run off away from hydrocarbon impacted soil stockpiles.

### **3.4 LANDFARM TREATMENT OF HYDROCARBON CONTAMINATED MATERIAL – NOT USED**

- .1 Prepare Landfarm Treatment Area
  - .1 Construct Landfarm Treatment Area in location shown on drawings.
  - .2 Construct Landfarm Treatment Area to accommodate all soil to be treated.
- .2 Excavate Hydrocarbon Impacted Soil and Treat to Criteria
  - .1 Excavate to elevations and dimensions as indicated by Owner.
  - .2 Transport hydrocarbon impacted material to Landfarm Treatment Area.
  - .3 Spread material within bermed area to a thickness not exceeding 300 mm
  - .4 Disc material, turn and mix materials regularly at intervals not to exceed 5 days until material meets the required criteria.
  - .5 The Owner will sample and analyze treated soils to confirm hydrocarbon concentrations using independent laboratories on a regular turnaround basis. There will be no standby time while waiting for the results of the confirmation samples.

- .6 Assist Owner in collection of representative soil and groundwater samples from the walls and base of the excavation.
- .7 Treated material that has met required criteria may be stockpiled or replaced in clean excavation.

### **3.5 EXCAVATE AND DISPOSE OFF SITE HYDROCARBON CONTAMINATED MATERIAL**

- .1 Excavate to elevations and dimensions indicated by Owner.
- .2 Transport Hydrocarbon impacted material to a disposal area or landfill approved by the Owner.
- .3 Supply a copy of the manifest or proof of receipt of material, acceptable to the Owner, from the disposal facility.

### **3.6 BACKFILL EXCAVATED AREAS**

- .1 Backfill all excavation areas, and fill to required sub-grade elevations using the treated soils, clean overburden, and additional imported materials as specified in Section 02330 Earthwork Materials.
- .2 Ensure backfill areas are free of debris, snow, ice and water. Do not backfill over porous, wet or spongy sub-grade surfaces.
- .3 Place backfill material in excavation in maximum 200 mm lifts to facilitate optimum compaction and compact using mechanical methods. Do not use hydraulic methods, vehicles or other equipment not designed for compacting.
- .4 Maintain optimum moisture content of materials being compacted, as required attain a specified compaction density of 97% of the Standard Proctor Density  $\pm 2\%$  of optimum.
- .5 Use care in backfilling to avoid damage or displacement of services.
- .6 Surface to be graded to ensure drainage away from backfilled areas.

### **3.7 RESTORE TREATMENT AREA**

- .1 Remove all material from site to disposal location acceptable to the Owner.

### **3.8 COLLECTION AND TREATMENT OF GROUNDWATER**

- .1 The Owner will determine the method of collection, treatment or disposal of groundwater:
  - .1 Use equipment and techniques authorized by the Owner.
  - .2 The collection, treatment or disposal of groundwater will be valued in accordance with Section 00725 – General Conditions, clause 8.3 - Valuation of Changes in the Work.

**END OF SECTION**